



Admire Paints Arttex Texture Archi Concrete highly recommended for Exterior and Interior surfaces is a Hybrid German Acrylic copolymer siloxane resin blended with ultra fine natural specially selected curvy minerals with the cutting edge technology makes it possible for a smooth desired pattern. It's overlapping ability with Crown Imperial Protective Coat Gloss finish and Tile Guard Colour Wash Matt finish with multiple colour options makes various elegant trendy concrete texture finishes possible.

BENEFITS

Ready To Use - Not to be Diluted | Suitable for Exterior and Interior surface | Highly Durable | Washable | Stain Resistant | UV Resistant | Anti-algae | Waterproof | Supreme Bonding | 2X Coverage

FEATURES

Finish	Standard, Exposed, Blasted, Honed, Buffed, Broomed and more
Type	Acrylic Copolymer siloxane Resin
Drying Time	Surface drying time 45 - 60 min
Colours	18+ colours available in CR/PC1 Clear Gloss and DM/TG1 Colour Wash Matt
Packing	1Kg / 25kg Bucket
Coverage*	1.00 - 1.50 sq.m/ Kg / Coat based on the substrate and surface condition.

APPLICATION

Clean the Surface thoroughly with 180 emery paper. Apply Admire Paints wall primer and allow it to dry for 3-4 hours. Smoothen the surface by applying 2-3 coats of Admire Paints Acrylic wall Putty giving 3-4 hours of drying time between each coat. Sand the surface with 180 emery paper and primer the surface again and allow it to dry for 3-4 hours. Apply 1st coat of ADMIRE Paints Archi Concrete without dilution using a steel trowel and allow it to dry for 45-60 mins. In a semi dry condition apply the 2nd coat of ADMIRE Paints Archi Concrete and make the desired pattern using the required tools. Allow it to dry for 5-10 mins and buff the surface gently using a steel trowel without flattening the pattern. After 6-8 hours of complete drying apply 1st coat of Admire Paints Crown Imperial Protective Coat PC1 Clear diluted (1lit with 2lit water). After drying for 3-4 hours wet the surface with water before applying 2nd coat PC1 tinted diluted (1lit with 2lit water) using sponge roller & cw sponge in the direction of the pattern. Remove excess material using wet CW sponge.

PRECAUTIONS: Do not apply when temperature below 10°C. Use of Stainers or colourants is not recommended. Thinning is not recommended. Do not keep material open for a long time. Product cannot be applied on surfaces/substrats that are subjected to continuous seepage or dampness. Stir well before use.

